

scRNA-seq: Quality Control

Meng Luo
A bioinformatician


Outline

- Intro Single-cell RNA-seq
- sc/nRNA-seq workflow
- Quality control:
 - Filtering low quality cells
 - Doublet cells
 - Filtering of genes
 - Removal of cell cycle effect
- PCA for quality control

✓ Why Single-cell RNA-seq?

- ✓ 为了更好的了解组织和存在的细胞类型，需要更高分辨率的技术
- ✓ scRNA-seq提供了在单个细胞水平上表达哪些基因的信息
- ✓ 探索组织中存在哪些细胞类型
- ✓ 识别未知/稀有的细胞类型或状态
- ✓ 阐明分化过程中或跨时间或不同状态下的基因表达变化
- ✓ 识别在特定条件下（例如，治疗或疾病）在特定细胞类型中差异表达的基


因




<https://www.cell.com/pictureshow>

✓ Common applications of single-cell RNA sequencing


a) Deconvolving heterogeneous cell populations




b) Trajectory analysis of cell state transitions



c) Dissecting transcription mechanics



d) Network inference




- 细胞异质性研究：能够鉴定**细胞亚型和稀有细胞类型**
- 细胞状态转变的轨迹分析：鉴定谱系**特异性基因表达**和驱动分支的**关键基因**
- 解剖转录动力学：转录爆发，基因在每个细胞中的**打开和关闭**
- 网络推断：推断模块，共同调节的基因-推断基因调节网络

✓ Challenges(complexities) of scRNA-seq analysis

- Large volume of data (high dimension)
 - Expression data from scRNA-seq experiments represent ten or hundreds of thousands of reads for **thousands of cells**. The data **output is much larger**, requiring **higher amounts of memory** to analyze, **larger storage** requirements, and more time to run the analyses
- Low depth of sequencing per cell
 - For the **droplet-based** methods of scRNA-seq, the depth of sequencing is shallow, often detecting **only 10- 50% of the transcriptome per cell**. This results in cells showing **zero counts for many of the genes**. However, in a particular cell, a **zero count for a gene** could either mean that the gene was **not being expressed** or the **transcripts were just not detected**. Across cells, genes with higher levels of expression tend to have fewer zeros. Due to this feature, **many genes will not be detected in any cell** and gene expression will be highly variable between cells.

✓ Challenges(complexities) of scRNA-seq analysis

- Biological
- Trajectory
- All genes
- Variability
- Rare cell types
- Continuous phenotypes
- Discrete types
- Spatial position
- Unidirectional temporal progression
- State vacillation




time for
each cell.
different
are by
is from
nce the
as cell

cycle, can affect the gene expression profiles of individual cells.

✓ Challenges(complexities) of scRNA-seq analysis

- Technical variability across cells/samples
 - Cell-specific capture efficiency: Different cells will have differing numbers of transcripts captured resulting in differences in sequencing depth (e.g. 10-50% of transcriptome).
 - Library quality: Degraded RNA, low viability/dying cells, lots of free floating RNA, poorly dissociated cells, and inaccurate quantitation of cells can result in low quality metrics
 - Amplification bias: During the amplification step of library preparation, not all transcripts are amplified to the same level.
 - Batch effects: Batch effects are a significant issue for scRNA-Seq analyses, since you can see significant differences in expression due solely to the batch effect.

✓ Challenges of scRNA-seq analysis



Stephanie C Hicks, F William Townes, Mingxiang Teng, Rafael A Irizarry, Missing data and technical variability in single-cell RNA-sequencing experiments, Biostatistics, October 2018.

✓ Challenges(complexities) of scRNA-seq analysis

- ✓ While scRNA-seq is a powerful and insightful method for the analysis of gene expression with single-cell resolution, there are many challenges and sources of variation that can make the analysis of the data complex or limited.

✓ Workflows

Samples

Human and mouse mixture



Rep1 Rep2 Rep3 Rep4

Human



Rep1 Rep2 Rep3 Rep4

Resection, biopsy, ascites
Fresh, Frozen


Mouse




Rep1 Rep2 Rep3 Rep4

Copyright
Meng Luo

PRE-PROCESSING



Quality control




Data correction (e.g. batch)



Normalization




Feature selection



Visualization



DOWNSTREAM ANALYSIS



SCUMI
Cumulus
Data analysis tools
Cellranger count

ion of exon mapping reads
-for full length methods
S2
A-mapping reads
per of UMIs/reads
per of detected genes
-in detection

ies

Hierarchical
k-Means
Graph-based
(scanpy, seurat...)

• Summary of 55 TI
methods
• Monocle, PAGA,
Slingshot

Infer CNV

GO, KEGG
Enrichment
TopGO

```

Beads-oligo-dT:

V2: |--5'- CTACACGACGCTCTTCCGATCT[16-bp cell barcode][10-bp UMI](T)30VN -3'
V3: |--5'- CTACACGACGCTCTTCCGATCT[16-bp cell barcode][12-bp UMI](T)30VN -3'

Template Switching Oligo (TSO): 5'- AAGCAGTGGTATCAACGCAGAGTACATrGrGrG -3'
cDNA Forward primer: 5'- CTACACGACGCTCTTCCGATCT -3'
cDNA Reverse primer:

V2: 5'- AAGCAGTGGTATCAACGCAGAGTACAT -3'
V3: 5'- AAGCAGTGGTATCAACGCAGAG -3'


Illumina Truseq Read 1 primer: 5'- TCTTTCCCTACACGACGCTCTTCCGATCT -3'
Illumina Truseq Read 2 primer: 5'- GTGACTGGAGTTCAGACGTGTGCTCTTCCGATCT -3'
Truseq adapter (double stranded DNA with a T overhang):

V2: 5'- GATCGGAAGAGCACACGTCTGAACTCCAGTCAC -3'
    3'- TCTAGCCTTCTCG -5'
V3: 5'- GATCGGAAGAGCACACGTCTGAACTCCAGTCA -3'
    3'- TCTAGCCTTCTCG -5'


Library PCR primer 1: 5'- AATGATACGGGACACCGAGATCTACACTCTTTCCCTACACGACGCTC -3'
Library PCR primer 2: 5'- CAAGCAGAAGACGGCATACGAGAT[8-bp sample index]GTGACTGGAGTTCAGACGTGT -3'
Sample index sequencing primer: 5'- AGATCGGAAGAGCACACGTCTGAACTCCAGTCAC -3'
Illumina P5 adapter: 5'- AATGATACGGGACACCGAGATCTACAC -3'
Illumina P7 adapter: 5'- CAAGCAGAAGACGGCATACGAGAT -3'

```


10X Chromium 单细胞转录组测序可分为3'端polyA 附近区域捕获和5'端转录起始位置附近捕获建库测序。3'端转录本测序适用于各种类型的细胞，对于10X 单细胞3'的V2 试剂盒处理的样本，Read 1 由16 bp 的10X 细胞Barcode 和10 bp 的UMI 序列组成；而V3 试剂盒处理的样本，Read 1 由16 bp 的10X 细胞Barcode 和12 bp 的UMI 序列组成。其中，10X chromium 的Barcode 用于标记单个细胞，存在于逆转录引物上的随机核苷酸序列上。Read 2 是151 bp 的cDNA 序列，一般只将前98 bp 用于下游分析。



Chromium Single Cell 3' Gene Expression Library



10X v3



inDrops v3

液滴方法:

- Sample index(样本索引): 确定read来自哪个样本(在库准备过程中添加—需要记录)
- Cellular barcode: 确定read来自哪个细胞(每种库制备方法都有在库制备过程中使用的细胞条形码的库)
- UMI(唯一分子标识符): 确定read来自哪个转录分子
- Sequencing read1: Read1序列
- Sequencing read2: Read2序列

✓ Take home message

nCount_RNA : 每个细胞的UMI数量

nFeature_RNA : 每个细胞检测到的基因数量


number of genes detected per UMI: 每个UMI检测到的基因(越多, 我们的数据就越复杂)

mitochondrial ratio: 自线粒体基因的细胞读数的百分比

Ribosomal ratio: 编码核糖体蛋白基因的UMI 序列比例


✓ Assessing the quality metrics

- Cell counts
- UMI counts per cell
- Genes detected per cell
- UMIs vs. genes detected
- Mitochondrial counts ratio
- doublets: doublets are generated from two cells. They typically arise due to errors in cell sorting or capture, especially in **droplet-based protocols** involving thousands of cells. **Doublets are obviously undesirable** when the aim is to **characterize populations** at the single-cell level.



✓ filtering in different ways and exploring variability data



- 3 different PBMC datasets from the 10x Genomics
 - 1k PBMCs using 10x v2 chemistry
 - 1k PBMCs using 10x v3 chemistry
 - 1k PBMCs using 10x v3 chemistry in combination with cell surface proteins, but disregarding the protein data and only looking at gene expression.



<https://support.10xgenomics.com/single-cell-gene-expression/datasets>



✓ filtering in different ways and exploring variability data

➤ QC-features :nFeature_RNA, nCount_RNA





✓ filtering in different ways and exploring variability data

➤ correlation




✓ filtering in different ways and exploring variability data

➤ Calculate mitochondrial, ribosomal proportion



✓ Doing filtering in different ways and exploring variability data

➤ Calculate mitochondrial, ribosomal proportion





➤ Gene detection filtering

- 被检测基因数量极高的可能表明doublets
- 基因检测方面，v2和v3也有明显的差异，数据的过滤不能用都采用相同的界限
- 有蛋白质分析数据中，有许多细胞几乎没有检测到的基因，但呈双峰分布。这种类型的分布在其他两个数据集中没有看到。考虑到它们都是PBMC数据集，把这个分布看作低质量的库是有意义的
- 过滤高基因检测的细胞(假定doublets)，v3的cutoff为4100，v2的cutoff为2000



➤ Mitochondrial filtering

- 有相当多的细胞具有高比例的线粒体reads。如果过滤后我们还有足够的细胞，最好去除这些细胞。另一种是从数据集中移除所有线粒体，剩余的基因仍然有足够的信号
- 以上数据分析中，有高达99.7%的线粒体存在细胞中，所以不太可能有很多细胞类型的标记留在这些细胞中
- 看图作出合理的决定，在哪里划出界限。看以上的数据中，大部分细胞的线粒体读数低于25%


➤ QC-Filterling :nFeature_RNA,nCount_RNA



➤ QC-Filterling :mitochondrial, ribosomal proportion



➤ Removal of cell cycle effect



- Calculating cell cycle scores based on a list of known S-phase and G2/M-phase genes.


➤ SCATER: pre-processing, quality control, normalisation and visualisation of single-cell RNA-seq data in R

- Most expressed features


```
[1] "orig.ident"
[2] "nCount_RNA"
[3] "nFeature_RNA"
[4] "Chemistry"
[5] "percent.mito"
[6] "percent.ribo"
[7] "S.Score"
[8] "G2M.Score"
[9] "Phase"
[10] "ident"
[11] "is_cell_control"
[12] "total_features_by_counts"
[13] "log10_total_features_by_counts"
[14] "total_counts"
[15] "log10_total_counts"
[16] "pct_counts_in_top_50_features"
[17] "pct_counts_in_top_100_features"
[18] "pct_counts_in_top_200_features"
[19] "pct_counts_in_top_500_features"
[20] "total_features_by_counts_endogenous"
[21] "log10_total_features_by_counts_endogenous"
[22] "total_counts_endogenous"
[23] "log10_total_counts_endogenous"
[24] "pct_counts_endogenous"
[25] "pct_counts_in_top_50_features_endogenous"
[26] "pct_counts_in_top_100_features_endogenous"
[27] "pct_counts_in_top_200_features_endogenous"
[28] "pct_counts_in_top_500_features_endogenous"
[29] "total_features_by_counts_feature_control"
[30] "log10_total_features_by_counts_feature_control"
[31] "total_counts_feature_control"
[32] "log10_total_counts_feature_control"
[33] "pct_counts_feature_control"
[34] "pct_counts_in_top_50_features_feature_control"
[35] "pct_counts_in_top_100_features_feature_control"
[36] "pct_counts_in_top_200_features_feature_control"
[37] "pct_counts_in_top_500_features_feature_control"
[38] "total_features_by_counts_mito"
[39] "log10_total_features_by_counts_mito"
[40] "total_counts_mito"
[41] "log10_total_counts_mito"
[42] "pct_counts_mito"
[43] "pct_counts_in_top_50_features_mito"
[44] "pct_counts_in_top_100_features_mito"
[45] "pct_counts_in_top_200_features_mito"
[46] "pct_counts_in_top_500_features_mito"
```

<https://bioconductor.org/packages/release/bioc/html/scater.html>


➤ Most expressed features



➤ Cumulative expression






- gene stats




<https://bioconductor.org/packages/release/bioc/html/scater.html>

- cell stats




<https://bioconductor.org/packages/release/bioc/html/scater.html>

➤ PCA for quality control: Identify outliers in QC-stats




On method of identifying low quality cells is to run PCA on all the qc-stats and then identify outliers in PCA space.

➤ PCA for quality control: Identify outliers in QC-stats




On method of identifying low quality cells is to run PCA on all the qc-stats and then identify outliers in PCA space.

➤ UMAP



➤ Explanatory factors



- Ding, J., et al. (2020). "Systematic comparison of single-cell and single-nucleus RNA-sequencing methods." *Nature Biotechnology* 38(6): 737-746.
- Hicks, S. C., et al. (2018). "Missing data and technical variability in single-cell RNA-sequencing experiments." *Biostatistics* 19(4): 562-578.
- Kang, H. M., et al. (2018). "Multiplexed droplet single-cell RNA-sequencing using natural genetic variation." *Nat Biotechnol* 36(1): 89-94.
- Klein, A. M., et al. (2015). "Droplet barcoding for single-cell transcriptomics applied to embryonic stem cells." *Cell* 161(5): 1187-1201.
- Liu, S. and C. Trapnell (2016). "Single-cell transcriptome sequencing: recent advances and remaining challenges." *F1000Res* 5.
- McCarthy, D. J., et al. (2017). "Scater: pre-processing, quality control, normalization and visualization of single-cell RNA-seq data in R." *Bioinformatics* 33(8): 1179-1186.
- Mereu, E., et al. (2020). "Benchmarking single-cell RNA-sequencing protocols for cell atlas projects." *Nat Biotechnol* 38(6): 747-755.
- Slyper, M., et al. (2020). "A single-cell and single-nucleus RNA-Seq toolbox for fresh and frozen human tumors." *Nat Med* 26(5): 792-802.
- Stuart, T. and R. Satija (2019). "Integrative single-cell analysis." *Nat Rev Genet* 20(5): 257-272.
- Wagner, A., et al. (2016). "Revealing the vectors of cellular identity with single-cell genomics." *Nature Biotechnology* 34(11): 1145-1160.
- Wagner, D. E. and A. M. Klein (2020). "Lineage tracing meets single-cell omics: opportunities and challenges." *Nat Rev Genet*.
- Ziegenhain, C., et al. (2017). "Comparative Analysis of Single-Cell RNA Sequencing Methods." *Mol Cell* 65(4): 631-643.e634.
- Wu, Y., Zhang, K. Tools for the analysis of high-dimensional single-cell RNA sequencing data. *Nat Rev Nephrol* (2020).
- Lafzi, A., Moutinho, C., Picelli, S. et al. Tutorial: guidelines for the experimental design of single-cell RNA sequencing studies. *Nat Protoc* 13, 2742–2757 (2018).
- Malte D Luecken; Fabian J Theis. Current best practices in single-cell RNA-seq analysis: a tutorial. *Mol Syst Biol.* (2019)

➤ 下期课程

❖ 降维与聚类（不同降维算法原理）

❖ 细胞亚群间表达差异分析

❖ 拟时序分析

❖ 细胞亚群注释

❖ 样本间表达量差异分析

ANY QUESTIONS!

谢谢!